

INSTRUCTIONS FOR HOOKUP AND ASSEMBLY OF #98 DISPLAY

The No. 98 Scenic Display comes completely wired and ready to attach the following equipment, No. 4b Transformer, No. 577 Whistle, No. 592 Crossing Gate, No. 751 Log Loader, No. 755 Talking Station and No. 758 "Sam" The Semaphore Man.

TO INSTALL EQUIPMENT

First place the Whistle, Talking Station and "Sam" The Semaphore Man in their respective locations in the layout, then insert wires from the equipment through the holes in the display base and the bared ends of these wires go to fahnstock clips on the underneath side which are marked for each piece of equipment. Care should be taken that the correct wires go to the clips. Namely - yellow wire to clip marked yellow, etc.

Next place the No. 751 Log Loader in its location and the Control Box should be dropped through the hole underneath it and brought up through the hole in the control section. Then mounted with 2 wood screws which are included. The yellow and black wires from the Control Box are then fastened to the respective clips underneath the base.

Next place the No. 592 Crossing Gate in its spot and connect the 2 wires protruding through the display base to the 2 terminals on the Crossing Gate.

Next fasten the 4b Transformer in place with the strap and bolts provided so that it cannot be knocked off the table. Now connect the three wires to their respective terminal posts on the transformer.

The upright backboard section of the display is then fastened to the base with the 4 ¼" carriage bolts provided.

The cartons, wires, Instruction Sheets, etc., which came with the operating equipment should be saved so material can be packaged for sale or future use.